



Electronic Platform Scales EF231

User Manual



■ FEATURES

1. Weigh directly on the platform or with your own mixing bowl
 2. Measuring liquids such as water or milk in ml or fl'oz
 3. Add & Weigh allows for measurement of multiple ingredients in the same bowl
- saves on washing up
 4. Switch between Metric and Imperial
 5. Easy to read LCD display
-

■ TO INSTALL OR REPLACE BATTERY


2X AAA batteries included

Ensure +/- terminals are the correct way round


■ LCD



■ BUTTONS ILLUSTRATION




■ WORKING MODES




■ TO CONVERT WEIGHT UNIT

If the scale is with both unit systems of Metric (g, ml) or Imperial (lb:oz, fl'oz), press **MODE** button to choose working mode (weight, milk volume, water volume), then press **UNIT** button to convert between two systems. Take the conversion of weight unit for example:




- When setting “g” as weight unit, the default volume unit is “ml”
- When setting “lb:oz” as weight unit, the default volume unit is “fl’oz”

■ TO START WEIGHING



1. Weighing mode


- Place the scale on a solid and flat surface.
- Place bowl (if used) on the scale before turning on the scale.
- Press **ZERO ON/OFF** to turn on the scale
- Wait until LCD shows "0" to start weighing. Press **MODE** to convert to weight mode if needed.
- Load weighing object on to start weighing, LCD will show the weight reading.
- If the weighing object is water or milk, press **MODE** button to choose volume mode and view the volume of weighing object.




2. Volume indication mode

- Place the scale on a solid and flat surface.
- Press **ZERO ON/OFF** to turn on the scale.
- Wait until LCD shows "0", and press **MODE** button to choose "Water" or "Milk" mode.
- Put a liquid container onto the scale platform.
- Press **ZERO ON/OFF** button to reset LCD to "0".
- Pour liquid (water or milk) into the container, LCD shows the volume of the liquid.
- Press **MODE** button to choose "Weight" mode and view the weight of liquid.

■ “ZERO” OR “TARE” FUNCTION

To weigh different loads consecutively without removing loads from the scale. Put first Load on the scale, get weight reading. Press  button to reset the LCD reading to "0" before adding next load. You can repeat this operation.





■ Condition 1: "ZERO" function

When total sum of all loads on scale $\leq 4\%$ of scale's max.weight capacity.

(4%=80g when capacity is 2000g;

200g when capacity is 5000g)

LCD will show ---- or 0g each time  is pressed. ---- means not stable, please wait for a moment. 0g and meanwhile an icon o on the left of LCD mean ZERO function is active. Max.weight capacity remains unchanged.




■ Condition 2: "TARE" function



When total sum of all loads on scale $> 4\%$ of scale's max.weight capacity.

(4%=80g when capacity is 2000g;


200g when capacity is 5000g)

LCD will show ---- or 0g each time  is pressed. ---- means not stable, please wait for a moment. 0g and meanwhile an icon T on upper left corner of LCD mean TARE function is active. Max. Weight capacity is reduced by total weight of all loads.

■ Under this condition:

By pressing , you can see the total weight of all loads on the scale. If you want to weigh more loads, just press  to reset LCD reading to '0' again.


■ AUTO SHUT OFF




Auto shut-off occurs if display shows '0' or shows the same weight reading for 2 minutes.


■ MANUAL SHUT OFF




To maximize battery life, always press  again to turn off the scale after using.

Note: when display shows "0", press  to turn off the scale;

when display shows weight reading, press

 for 3 seconds to turn off the scale.

■ WARNING INDICATORS



1. Replace new battery.
2. Scale overload. Remove item to avoid damage. Max. weight capacity is indicated on the scale.

■ **CLEANING AND CARE**

1. **Clean the scale with a slightly damp cloth. DO NOT immerse the scale in water or use chemical / abrasive cleaning agents.**
2. **All plastic parts should be cleaned immediately after contact with fats, spices, vinegar and strongly flavored / colored foods. Avoid contact with acids citrus juices.**
3. **Always use the scale on a hard, flat surface. DO NOT use on carpet.**
4. **DO NOT strike, shake or drop the scale.**

■ **DISPOSAL**



Under WEEE regulations this product must not be disposed of as household waste. To prevent damage to the environment and humans this product must be disposed of in an approved and environmentally friendly recycling process. For more information on how to dispose of this correctly please contact your Prepara distributor or local authority responsible for waste disposal.

Bunzl Lockhart Catering Equipment

Lockhart House, Brunel Road, Theale, Reading, Berkshire, RG7 4XE, U.K.